

LEVELING AND STABILIZATION

If just one of the landing gear legs needs to be replaced, please note the following attributes:

- The length of the outer black tube 29 $\frac{1}{2}$ " or 33 $\frac{1}{2}$ ".
- The leg is the drive or the idler*
 - * Leg with motor attached is identified as "drive side."
 - * Leg with no motor mounted at the top is identified as "idler."
- The leg is mounted to the inside or outside of the frame rail.
- The cap on top is press fit or held on by screws.

Compare the four attributes of the jack needing replaced with the chart below to determine the correct jack to be ordered:

	<u>119101</u>	<u>119102</u>	112532	<u>122533</u>	<u>126385</u>	<u>126386</u>	<u>177201</u>	<u>177202</u>	<u>179013</u>	<u>179014</u>
					LENGTH					
29 ½"	Х	Х	Х	Х					Х	Х
33 ½"					Х	Х	Х	Х		
					DRIVE					
Motor		Х		Х		Х		Х	Х	
ldler	Х		Х		Х		Х			Х
					MOUNT					
Inside Frame	х	x			х	х			х	х
Outside Frame			х	х			х	х	х	х
					CAP					
Press Fit	Х	Х	Х	Х	Х	Х	Х	Х		
With Screws									х	х

As a supplier of components to the RV industry, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at (574) 537-8900 or by email at <u>customerservice@lci1.com</u>. Self-help tips, technical documents, product videos and a training class schedule are available at <u>lci1.com</u> or by downloading the MyLCI app.

U-155